WIRING DIAGRAM ZONE MOTOR TERMINAL BLOCKS MA-ND/ND2/ND3 ZONE3 MA-URD **MOTOR** 6 M6 **M4** 0 4 **M2** 1 MA-ND/ND2/ND3 **ZONE2** MA-URD **MOTOR** 6 M6 0 **M4** 4 **M2** 0 0 AFR-2 AFR-1-NO AFR-2-NO AFR-3 MA-ND/ND2/ND3 NC(2) C(1) NO(3) MA-URD 6 4 NOTE: AFR RELAYS -- MODEL R1, SPDT RELAY W/ 24VAC COIL DWG NAME: MODEL ND/URD -- ADDITIONAL DAMPER DRAWING BY: **EDK** 11/29/04 WIRED FOR ZONES 2 & 3 SIZE: REV: DISCLAIMER: EWC Controls Inc., Cannot be held liable for the use or misuse of DISCLAMENT. EVEN CONTROLS INC., Cannot be riled lable for the user of release or misuse of this supplied information. It is the responsibility of the user to determine the suitability of the application. Malfunctions, improper operation, and/or subsequent damage to any related equipment or property damage as a result of using this supplied information is the responsibility of the user. EWC Controls Inc., is not responsible for any misapplications including, but not limited to negligence, defect in products(s), system incompatibility, poorworkmanship and/or installation. 090512A0050 CONTROLS INC. Α Englishtown, NJ 07726 SHEET: COPYRIGHT © EWC CONTROLS INC. ALL RIGHTS RESERVED 1 OF 1