WIRING DIAGRAM AFR4 MODEL EWT-261 BMPlus 3000 OR EQUIVALENT **ZONE 1 & 2** T'STAT INPUTS C AFR3 W **ZONE2** T'STAT В AFR1-2-NC AFR2-2-NC 00 O~}/{~ RH (/)AFR1-1-NC AFR2-1-NC RC G JUMPER MODEL EWT-261 ZONE1 T'STAT OR EQUIVALENT C AFR3-2-NC AFR4-2-NC ~//0---0//0-(/)W **W2** AFR3-1-NC AFR4-1-NC 01/6-01/6 В \bigcirc O RH AFR2 RC EM ONE G **JUMPER ZONE** *NOTE: AFR(1-4) -- DPDT RELAY W/ 24VAC COIL DWG NAME: BMPlus3000 -- WIRED W/ ZONE DRAWING BY: DATE: **EDK** 03/08/05 PRIORITY LOCK-OUT RELAYS SIZE: REV: DISCLAIMER: EWC Controls Inc., Cannot be held liable for the use or misuse of DISCLAMENT. EVEC CONTROLS INC., Calmito de filed liable ion in less of misses of this supplied information. It is the responsibility of the user to determine the suitability of the application. Malfunctions, improper operation, and/or subsequent damage to any related equipment or property damage as a result of using this supplied information is the responsibility of the user. EWC Controls Inc., is not responsible for any misapplications including, but not limited to negligence, defect in product(s), system incompatibility, poor workmanship and/or installation. 090512A0089 CONTROLS INC. Α

COPYRIGHT © EWC CONTROLS INC. ALL RIGHTS RESERVED

Englishtown, NJ 07726

SHEET:

1 OF 1